

**ATTENTION SERVICE PERSONNEL  
AIR HANDLER CONTROL SET-UP  
PLEASE KEEP WITH UNIT FOR FUTURE USE!  
7-SEGMENT DISPLAY AND CONFIGURATION  
GUIDE**

Refer to unit installation instruction for configuring unit size code and electric heat.

**Unit Size Codes For Air Handlers**

Unit Size Code	Air Handler Model	Unit Size Code	Air Handler Model	Unit Size Code	Air Handler Model
0	CBX32MV-018, -024	6	CBX40UHV-024	A	CBA38MV-018, -024
1	CBX32MV-024, -030	7	CBX40UHV-030	C	CBA38MV-030
2	CBX32MV-036	8	CBX40UHV-036	E	CBA38MV-036
3	CBX32MV-048	9	CBX40UHV-042	F	CBA38MV-042
4	CBX32MV-060	L	CBX40UHV-048	H	CBA38MV-048
5	CBX32MV-068	U	CBX40UHV-060	Y	CBA38MV-060

Code	Action
<b>Power-Up</b>	Unit Size Code (number or letter) represents air handler model size and capacity. Refer to <i>Unit Size Codes For Air Handlers</i> table above. If three horizontal bars are displayed, AHC does not recognize size and capacity.
<b>•</b>	Idle mode — decimal blinks at 1 Hertz > 0.5 second ON, 0.5 second OFF. Idle mode is when the system is energized but no demand.
<b>A</b>	Cubic feet per minute (CFM) setting for indoor blower - 1 second ON, 0.5 second OFF > CFM setting for current mode displayed.
<b>C</b>	Cooling stage — 1 second ON, 0.5 second OFF > 1 or 2 displayed > pause > CFM setting displayed > pause > repeat codes).
<b>d</b>	Dehumidification mode — 1 second ON > pause > CFM setting displayed > pause > repeat codes.
<b>d F</b>	Defrost Mode
<b>H</b>	Heat Stage is 1 second ON, 0.5 second OFF > 1 or 2 displayed > pause > CFM setting displayed > pause > repeat codes. Electric heat available in 1 to 5 stages.
<b>h</b>	Stage heat pump (shows active heat pump stages, h1 or h2)
<b>U</b>	Discharge air sensor temperature (discharge air sensor must be installed, properly configured and indoor blower must be operating).

Code	Action
<b>Indoor Blower Test</b>	
<b>A</b>	Release push button — Control cycles indoor blower on for 10 seconds at 70% of maximum air for selected capacity size unit. Control will automatically exit <i>Field Test Mode</i> .

Error Code Recall Mode (Note - control must be in idle mode)		
<b>E</b>	<b>E</b>	To enter <i>Error Code Recall Mode</i> , push and hold button until solid <b>E</b> appears, then release button. AHC will display up to 10 error codes stored in memory. If <b>E000</b> is displayed, there are no stored error codes.
Solid	- - -	To exit <i>Error Code Recall Mode</i> push and hold button until solid <b>three horizontal bars</b> appear, then release button. Note - Error codes are not cleared.
Solid	<b>c</b>	To clear error codes stored in memory, continue to hold push button while the <b>three horizontal bars</b> are displayed. Release push button when solid <b>c</b> is displayed.
Blinking	<b>c</b>	Push and hold for one (1) second, release button. Seven-segment will display 0000 and exit error recall mode.
Error	Status of Air Handler	
<b>E105</b>	The air-handler has lost communication with the rest of the system. Check for mis-wired and/or loose connections between the thermostat, indoor unit and outdoor unit. Check for a high voltage source of noise close to the system. This is a self-recoverable error.	
<b>E114</b>	There is a frequency/distortion problem with the power to the air-handler. Check the voltage and line power frequency	
<b>E115</b>	The 24VAC to the air-handler control is lower than the required range of 18 to 30VAC. Check the voltage and line power frequency.	
<b>E120</b>	There is a delay in the air-handler responding to the system. Check all wiring connections.	
<b>E124</b>	The iComfort thermostat has lost communication with the air-handler for more than 3 minutes. Check the wiring connections, ohm wires and cycle power.	
<b>E130</b>	An air-handler configuration jumper is missing.	
<b>E131</b>	The air-handler control parameters are corrupted. Replace control.	
<b>E132</b>	The air-handler control software is corrupted. Replace control.	
<b>E180</b>	The iComfort thermostat has found a problem with the air-handler outdoor sensor. Compare outdoor sensor resistance to temperature/resistance charts in unit installation instructions. Replace sensor pack if necessary.	
<b>E201</b>	The system has lost communication with the air-handler indoor blower motor. Check for loose wiring.	
<b>E202</b>	The unit size code for the air-handler and the size of blower motor do not match. Reconfigure control.	
<b>E203</b>	The unit size code for the air-handler has not been selected. Configure unit size code.	

<b>E292</b>	The air-handler's blower motor will not start. Check for seized bearing, stuck wheel, obstruction etc.
<b>E295</b>	The indoor blower motor is overheating. Check motor bearings and amps. Replace if necessary.
<b>E310</b>	There is a problem with air-handler discharge air sensor. Compare outdoor sensor resistance to temperature/resistance charts in installation instructions. Replace sensor if necessary.
<b>E312</b>	The blower cannot provide the requested CFM due to high static. Check filter and duct system.
<b>E313</b>	The indoor and outdoor unit capacities do not match.
<b>E345</b>	The <b>O</b> relay on the air-handler has failed. Either the pilot relay contacts did not close or the relay coil did not energize.
<b>E346</b>	The <b>R to O</b> jumper was not removed on the air-handler control.
<b>E347</b>	The <b>Y1</b> relay on the air-handler has failed. Either the pilot relay contacts did not close or the relay coil did not energize.
<b>E348</b>	The <b>Y2</b> relay on the air-handler has failed. Either the pilot relay contacts did not close or the relay coil did not energize.
<b>E350</b>	The air-handler's electric heat is not configured.
<b>E351</b>	There is a problem with the air-handler's first-stage electric heat. Either the pilot relay contacts did not close, or the relay coil in the electric heat section did not energize.
<b>E352</b>	There is a problem with the air-handler's second-stage electric heat. Either the pilot relay contacts did not close, or the relay coil in the electric heat section did not energize. The air-handler will operate on first-stage electric heat until the issue is resolved.
<b>E353</b>	There is a problem with the air-handler's third-stage electric heat. Either the pilot relay contacts did not close, or the relay coil in the electric heat section did not energize. The air-handler will operate on first-stage electric heat until the issue is resolved.
<b>E354</b>	There is a problem with the air-handler's fourth-stage electric heat. Either the pilot relay contacts did not close, or the relay coil in the electric heat section did not energize. The air-handler will operate on first-stage electric heat until the issue is resolved.
<b>E355</b>	There is a problem with the air-handler's fifth-stage electric heat. Either the pilot relay contacts did not close, or the relay coil in the electric heat section did not energize. The air-handler will operate on first -stage electric heat until the issue is resolved.
<b>E409</b>	The secondary voltage for the air-handler has fallen below 18VAC. If this continues for 10 minutes, the iComfort thermostat will turn off the air-handler.
See unit installation instruction or information manual for details on clearing the alarms.	



# JUMPER & LINK GUIDE

