

COMMERCIAL TRAINING TOOLBOX TIPS

ComfortSense 7500 Setup – Select Sensor Types

Applies to Lennox ComfortSense 7500 Commercial Thermostats

Helpful Resources

- 1. Lennoxcommercial.com or LennoxPros.com
- 2. ComfortSense 7500 Commercial Installation and Setup Guide 507506

Before Setup

- 1. All thermostat mounting and all wiring connections must be completed prior to setting up the thermostat.
- 2. Note the type of equipment, number of stages, and any accessories being installed.
- 3. This thermostat is a 24VAC low-voltage thermostat and requires a common wire to the thermostat to operate.
- 4. Use 18 gauge or larger thermostat wire between the thermostat and any optional remote temperature sensor (may be separate wire pair or two wires of a multi-wire cable for outdoor temperature sensor).
- 5. Ensure load from any thermostat connection is less than 1 AMP.
- 6. Wire run should not exceed 300 feet (91m).



Sensor Terminal Designations				
Ti	Remote indoor temperature sensor			
Тс	Sensor common terminal			
То	Outdoor or discharge air temperature sensor			

MORE Training Toolbox Tips Available! Click here to download them all. Self-Service Technical Support with No Wait Times! Click the black logos to download these apps.



Click here to register for any of the Lennox Commercial Product Technical Training Webinars.





ComfortSense 7500 Setup – Select Sensor Types

Applies to Lennox ComfortSense 7500 Commercial Thermostats

Setup

1. Press the Menu option.



2. Press and hold the settings option.



3. Confirm that you are qualified to adjust the controller settings.



4. Press the Sensor Setting option.

<	installer settings	
	system setup	>
	sensor setting	>
	residual cool	>
	dead band	>
	smooth set recovery	>
	ssr stage 2 lock out	>

5. Press the sensor type.

	<	discharge air	sensor setting			
	in	door sensor remote 10K remote 20K internal				
	12" duct probe sensor model 99K64 or 58W63 Select the REMOTE 10K 6" duct probe sensor model 19L22 Select REMOTE 20K					

NOTE – When a remote sensor is installed, the remote sensor is the only zone temperature used to control unit operation. There is no averaging between the remote sensor and the thermostat sensor.

