







KEY	COMPONENT
A146	CONTROL, BACNET
A63	SENSOR, CO2
A183	CONTROL, VFD BOARD
H1	HEADER 1 ON VFD BOARD
J3/P3	JACK/PLUG, ECONOMIZER OR BYPASS
K253-1	RELAY, ECON FDD
K264	RELAY, A96 SIGNAL SWITCHING
R1	SENSOR, MIXED AIR OR SUPPLY AIR
TB1	TERMINAL STRIP, CLASS II VOLTAGE

-  REMOVE P3 WHEN ECONOMIZER IS USED
-  J3 MAXIMUM LOAD 20VA 24VAC CLASS II
-  ONLY USED ON UNITS WITH JADE (W7220) ECONOMIZER CONTROL

 DENOTES OPTIONAL COMPONENTS  
 CLASS II FIELD WIRING

2022/07		WIRING DIAGRAM	08/22
		538307-01	
CONTROLS			
CONTROL FOR BACNET MODULE - EL_XA UNITS			
SECTION C			REV. 0
Supersedes		New Form No. 538307-01	